

SECTION XI TAIL GUNNER'S COMPARTMENT

1. ENTRANCE.

There are two ways of entering the tail gunner's compartment: one from the tail wheel compartment through a small door in the bulkhead, and one from the outside through a side door. The latter is used for emergency exit, and is equipped with an emergency release handle.

2. LIGHTING.

A dome light and switch are located above the gun handles behind the armor plate.

3. INTERPHONE.


The jack box is on the right side of the compartment looking aft above the aft end of the ammunition box. Refer to section I, paragraph 10.

4. OXYGEN.

Two oxygen regulators are provided, one on each side wall. Refer to section I, paragraph 9.

5. SUIT HEATER OUTLET.

A rheostat control, provided for use with the gunner's heated suit is adjusted to obtain the desired temperature in the suit.



KEY TO FIGURE 78

- | | |
|-----------------------|-----------------------|
| 1. AMMUNITION BOXES | 2. ARMOR PLATE |
| 3. KNEE PADS | 4. TAIL GUNNER'S SEAT |
| 5. INTERPHONE JACKBOX | |

Figure 78 - Tail Gunner's
Compartment

Figure 79 - Tail Gunner's
Compartment Door

