



Figure 23 - Navigator's Compartment (Aft View)

- |   |  |
|---|--|
| 213 Command Set Modulator               | 223 Left Engine Generator Switch                       |
| 214 Dynamotor                           | 224 Active Inverter Switch                             |
| 215 Command Set Antenna Switching Relay | 225 Generator Voltage Switch                           |
| 216 Fuel Transfer Pump Switch           | 226 Right Engine Generator Switch                      |
| 217 Command Set Receiver                | 227 Emergency Fuel Shut-Off Valve                      |
| 218 Command Set Transmitter             | 228 Emergency Spring Catch on Emergency Shut-Off Valve |
| 219 Passageway Over Bomb Bay            | 229 Fuel Flow Direction Switch                         |
| 220 Hydraulic System Foam Tank          | 230 Transfer Pump Indicator Light                      |
| 221 Fuel Transfer Valve                 | 231 Emergency Fuel Transfer Pump Switch                |
| 222 Fuel Transfer Valve                 |  |