



SPEED BRAKE SWITCH

SIGHT ELECTRICAL
CAGING BUTTON

MICROPHONE BUTTON

GRIP ROTATED FOR SIGHT
MANUAL RANGING (SPRING-
LOADED TO FULL COUNTER-
CLOCKWISE POSITION)

THROTTLE MOVEMENT
THROUGH IDLE STOP

F-86F-1-43-1A

throttle grip

© 2006 www.zenoswarbirdvideos.com

Figure 1-9