


**cockpit  
left side**  
F-86F-1 THROUGH F-86F-20  
AIRPLANES

1. Anti-G Suit Pressure-regulating Valve
2. Circuit-breaker Panel
3. Ammunition Compartment Heat Emergency Shutoff Handle
4. Ammunition Compartment Overheat Warning Light
5. Air Outlet Selector Lever
6. Windshield Anti-icing Overheat Warning Light
7. Console Floodlight
8. Side Air Outlet
9. Windshield Anti-icing Lever
10. Throttle
11. Rocket Intervalometer
12. Canopy and Windshield Auxiliary Defrost Lever
13. Instrument Panel Floodlight and Extension Light Alternate Mounting
14. Console Panel

15. Parking Brake Handle
16. Canopy Switch
17. Instrument Panel Floodlight
18. Emergency Jettison Handle
19. Type D-1 or D-2 Oxygen Regulator Panel
20. Forward Console
21. Throttle Friction Wheel
22. Wing Flap Lever
23. Speed Brake Emergency Lever
24. Flight Control Switch
25. Longitudinal Alternate Trim Switch
26. Rudder Trim Switch
27. Cockpit Pressure Control Switch
28. Lateral Alternate Trim Switch
29. Cockpit Pressure Schedule Selector Switch
30. Cockpit Air Temperature Control Rheostat
31. Aft Console
32. Cockpit Air Temperature Control Switch
33. Drop Tank Pressure Shutoff Valve
34. Extension Light \*

\* Some airplanes (Refer to applicable text)



F-86F-1-00-69B

Figure 1-10