

• SPECIFICATIONS

- FUEL** —JP-4 (MIL-J-5624)
ALTERNATE **
- OIL** —MIL-O-6081, GRADE 1010
ALTERNATE-MIL-O-6081, GRADE 1005
BELOW —29°C, USE GRADE 1005.
- HYDRAULIC FLUID** —MIL-H-5606
- ALCOHOL** —MIL-A-6091
- OXYGEN** —BB-O-925

servicing diagram



- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Battery 2. External AC Power Receptacle* 3. Nose Gear Emergency Lowering System Accumulator 4. Flight Control Normal Hydraulic System Accumulator 5. Fuel Filter Deicing System Alcohol Tank 6. External DC Power Receptacles 7. Aft Fuselage Fuel Tank Filler 8. Flight Control Alternate Hydraulic System Fluid Level Indicator Access Door 9. Left Wing Fuel Tank Filler 10. Left Drop tank Filler | <ul style="list-style-type: none"> 11. Oxygen Filler Valve 12. Forward Fuselage Fuel Tank Upper Cell Filler (Filled first to utilize full tank capacity) 13. Utility Hydraulic System Reservoir 14. Right Wing Fuel Tank Filler 15. Right Drop Tank Filler 16. Engine Oil Tank 17. Forward Fuselage Fuel Tank Lower Cell 18. Flight Control Alternate Hydraulic System Accumulator (Accumulators*) 19. Flight Control Normal Hydraulic System Fluid Level Indicator Access Door |
|---|--|

*Some airplanes. (Refer to applicable text.)

**Refer to Fuel Grade Properties and Limits this section.

Figure 1-38