



1. EMERGENCY ENCLOSURE RELEASE
2. MAP CASE
3. FUEL SYSTEM DIAGRAM
4. TAIL WHEEL CASTER LOCK
5. S.B.A.E ATTITUDE CONTROL
6. EMERGENCY ELEC. FUEL PUMP SWITCH
7. MIXTURE CONTROL
8. THROTTLE CONTROL
9. SUPERCHARGER CONTROL
10. CONTROL QUADRANT FRICTION ADJUSTMENT
11. RUDDER TAB CONTROL
- 12.AILERON TAB CONTROL
13. ELEVATOR TAB CONTROL
14. ARRESTING HOOK SWITCH
15. OXYGEN PLUG-IN
16. FLAP B LANDING GEAR CONTROL UNIT
17. LANDING GEAR EMERGENCY RELEASE
18. WING & TAIL SURFACE DE-ICING CONTROL

PILOT'S COCKPIT-LEFT HAND SIDE

FIG. 7