


www.zenoswarbirdvideos.com



- | | |
|-----------------------------------|------------------------------------|
| 1. Turret Light Switch | 9. High Speed Switch |
| 2. Elevation Power Switch | 10. Main Control Grip |
| 3. Train (Azimuth) Power Switch | 11. Trigger Switch |
| 4. Safety Catch - Charging Handle | 12. Microphone |
| 5. Firing Solenoid Overload Reset | 13. Interphone Control Box |
| 6. Gun Charging Handle | 14. Radio Key |
| 7. Dead Man's Switch | 15. Clutch Lever - Train (Azimuth) |
| 8. Master Power Switch | 16. Manual Crank - Elevation |
| | 17. Amm. Container Release |

TURRET CONTROLS DIAGRAM

FIG. 1