



www.zenoswarbirdvideos.com

Figure 78 — Martin Power Turret

WARNING

To avoid accidents, the master switch should always be in the "OFF" position when the operator is entering or leaving the turret.

2. Ascertain whether one or two seat cushions are to be used and snap them into place on the seat.
3. Grasp the handles that are provided on the turntable casting above the seat and with both feet on the footrest slam the seat closed.

CAUTION

Do not use the sight link rods as handles.

(b) TURRET CONTROLS. (See figure 79.)

1. After being properly strapped in place, reach under the front edge of the seat and close the master switch on the right-hand side of the junction box.
2. Place both hands on the control grips, thereby operating the deadman switches and starting the amplidyne motor generators.

NOTE

Unless at least one of the deadman switches is depressed, the turret will not operate.